

Eurocarts Cargo Trike

Thanks for buying the eurocarts cargo trike. Once you have assembled the trike I'm sure you will be keen to get out and take it for a ride. Hang on! there are a few things you need to know about riding a trike before you set off.

1. Always make sure all the relevant nuts, bolts and screws are securely fastened, even if they were on when you got the trike, you need to check!
2. Put the seat to the correct height so your leg just has a slight bend when extended on the pedal. Remember it does not have to touch the floor, you won't fall off when you stop.
3. Get use to the coaster brake. start slowly and stop the trike, make sure you can use it well before building up any speed, going down hill or carrying a load. It's always best to have the crank in the horizontal position when not pedaling or going down hill so you can apply pressure when needed to the brake. It takes a little getting use to but works great once you have the hang of things.
4. As the brakes, chain and pedals are linked, it is essential you make sure the pedals are always on tight and you should check these regularly along with the screw holding the coaster brake to the frame and chain condition.
5. When you first ride the trike it will feel unstable on bends, this is normal and takes a little practice. You must lean into the bends when turning or the trike or it will tip. The more load you carry the more stable the trike, it is a cargo trike. Take it slow to start and learn how to ride safely, remember it is not a bike.
6. If you ride across a hill the trike will always try and turn up the hill, this is physics and there is nothing you can do about this. If the trike is always turning to one side check the rear wheel has been put on straight and there is equal pressure in each front tyre.
7. The trike can carry loads up to 150kg. If carrying a large cargo you must not let the trike "get away from you", keep it slow, stay in control, this is a low speed cargo trike, now a race bike or BMX!
8. If traveling on a public road you MUST wear a helmet and it is recommended to fit lights and a mirror. Remember it is much wider than a bike and extreme care must be taken if using on the road or near people

Eurocarts can take NO responsibility for injury or accident from misuse of the trike or incorrect set up. Using the trike is solely your responsibility.

If you wish to return the trike for any reason within the first 14 days of receiving the trike you may do so, but the trike must be in the same condition as sent and in the original packaging. A packing and postage charge may apply.